



Plaza HDR-S: How to update the software to v1.5.3

Updating the software

1. Unzip and extract the downloaded file onto your computer.
2. You will find a folder named **update**. Copy this folder to the root directory of a USB memory stick that is formatted with the FAT32 filesystem. This is the the default when you format a USB stick using Windows.
3. Connect the USB memory stick to the USB connector at the back of the receiver and wait for 15 seconds.



4. Press the **MENU** button to display the **Main Menu** options. Press the **Down** button until the **Setup** option is highlighted then press the **OK** button. The **Setup** screen will be displayed.



5. Press the **Left** button once to highlight the **System** setup option. Press the **Down** button until the **Software Update via USB** option is highlighted, then press the **OK** button.



6. Updating will start automatically and the **Update via USB** screen will be displayed. Please wait until the update is finished, the receiver will reboot and display the current channel on your TV screen. Disconnect the USB memory stick after the update is finished.

NOTE: If the receiver displays **USB not connected or does not contain valid update software**, please check that you have copied only the **update** folder to the root directory of the USB or try with another USB Memory stick that is FAT32 formatted.



7. The new Software Version is displayed in the **Information** menu. To check, press the **MENU** button and then press **Down** until the **Information** option is highlighted, then press the **OK** button. The software version displayed should be "v1.5.3". Press the **EXIT** button after you have finished checking.