

Manhattan Plaza HD-S2 - How to update software to version 1.26

IMPORTANT

Please note that due to the changes in this release, the receiver will automatically reset to factory default and all user settings such as below will be lost!

- Favourites
- Reminders
- Deleted channels
- Settings

After reset, the installation process will start. Please follow the on-screen prompts and if you need assistance refer to the "Tuning In" section on page 12 of the User Guide.

Updating the software


1. Unzip and extract the downloaded file onto your computer.
2. Copy **usb.bin** file to the root directory of a USB memory stick that is formatted with the FAT32 file system. This is the default when you format a USB stick using Windows.




3. Connect the USB memory stick to the USB connector at the back of the receiver and wait until TV screen displays **USB Inserted** for a few seconds.



4. Press the **MENU** button to display the **Setup** options. Press the **Left** button once to highlight the **System** setup option. Press the **Down** button until the **Software Update via USB** option is highlighted, then press **OK** button.



5. **Software Update via USB** screen will be displayed. Press **OK** button when **Yes** option is highlighted. The software update will start after a few seconds followed by displaying the below updating screen.



Information and update progress

UPGRADING SOFTWARE PLEASE DO NOT TURN OFF

Updating software please wait until finished. After update, the receiver will reboot and display the **Freesat Installation** screen. Disconnect the USB memory stick and install the receiver.



Information Menu

You can check the updated Software Version in the **Information** menu. Press **MENU** button then highlight **Information** and press **OK**. Press **OK** or **EXIT** button after you have finished checking.