

Manhattan Plaza HD-T2 - How to upgrade the software to v1.35

IMPORTANT

Please note that due to the changes in this release, the receiver will automatically reset to factory default and all user settings such as below will be lost!

- Favourites
- Reminders
- Deleted channels
- Settings

After reset, the installation process will start. Please follow the on-screen prompts to install and if you need assistance refer to the “**Tuning In**” section on page 12 of the User Guide.

Updating the software


1. Unzip and extract the downloaded file **Plaza HD-T2 v1.35 update.zip** onto your computer.
2. You will find a file named **DTT1810_USB.bin**. Copy this file to the root directory of a USB memory stick that is formatted with the FAT32 filesystem. This is the the default when you format a USB stick using Windows.



3. Connect the USB memory stick to the USB connector at the back of the receiver and wait until TV screen displays **USB Inserted** for a few seconds.



4. Press **MENU** button to display the **Setup** options. Press the Left button once to highlight **System** setup. Press the Down button and highlight the **Software Update via USB** option then press the OK button.



5. **Software Update via USB** screen will be displayed. Press the OK button when **Yes** option is highlighted and the software upgrade will start after a couple of seconds followed by displaying below updating screen.



Information and update progress

UPGRADING SOFTWARE PLEASE DO NOT TURN OFF

Updating software please wait until finished. After update, the receiver will reboot and display the **Freeview Installation** screen. Disconnect the USB memory stick and install the receiver.



Information Menu

You can check the upgraded Software Version in the **Information** menu. Press **MENU** button then scroll down to **Information** and press OK. Press the **EXIT** button after you have finished checking.